

p i g P R O™

Series 57

Visual Indication

Manual Reset



THE BASE MODEL 57 IS A VISUAL FLAG INDICATOR WITH MANUAL RESET.

It is a popular member of Apache's pigPRO Series, a patented line of intrusive pig passage indicators that reliably detect the precise location of a cleaning pig as it travels within the pipeline network. When a cleaning pig passes the system's intruding plunger, it activates the plunger and triggers a visual flag indicator, signaling the pig's location.

Features:

Our most popular pigPRO™, the base Model 57 includes a thread mounting nipple, standard lower housing with fluorocarbon O-Rings, hemispherical plunger with a flag assembly.

Options:

Flange Mount -Flange base models are manufactured to mount to existing flanged connections and are available in class 150, 300, 600 or 900 ANSI flanges. Conversions kits are also available which enable installation onto the mountings of other manufacturers.

Extension Pole:

Aluminum extensions can be attached to enable detection of the pigs passage on buried pipelines. All pressure sealing components remain below the extension module. Available in lengths 2' to 8'.



Check out apachepipe.com/animations.html for videos on pigPRO™

1575 - 90 Ave Edmonton, AB Canada T6P 0E2

1-8

Ph: 780.416.4850 | Fax: 780.416.4829 | apachepipe.com | Email: sales@apachepipe.com

world class world wide